

New units

Description	LED Action/s	Graphical Representation (each block is approximate ½ sec)
New K1 unit (Default before starting)	Blinks green then red every 4.5 seconds	
<i>Do not press push button until ready to start the unit</i>		

To Start

Description	LED Action/s	Graphical Representation (each block is approximate ½ sec)
Press push button and hold for 10-15 seconds	Green LED will light then both red & green LEDs will light	
Release push button, K1 starting	Green LED blinks every 0.5 seconds	

Start Delay

(Description, Action and Graphical representation blue bar goes here)

Start delay (Until start delay time is met)	Blinks green then red every second	
No start delay	Green LED blinks once, every 6.8 seconds	

Indication Activity

Description	LED Action/s	Graphical Representation (each block is approximate ½ sec)
Low temp. excursion In Total & Consecutive Delay	Two green blinks every 4.8 seconds	
High temp. excursion In Total & Consecutive Delay	Two green blinks every 4.8 seconds	
Low temp. excursion With or without Total & Consecutive Delay	One red blink every 6.8 seconds	
Only High temp. excursion With or without Total & Consecutive Delay	Two red blinks every 5.7 seconds	
Both High & Low temp. excursion With or without Total & Consecutive Delay	Three red blinks every 4.8 seconds	

To Stop

Description	Action	Graphical Representation (each block is approximate ½ sec)
Press (push button) and hold it for 10-15 seconds	Green LED will light then both red & green LEDs will light	
Release button, K1 stopping	Red LED will blink every 0.5 seconds	

Alarm LED's will keep blinking in respective pattern, until the battery drains